

NOTE TO LUBEKAT USERS

Thank you for purchasing LUBEKAT. Below is some basic information about LUBEKAT use:

Because LUBEKAT has a higher alkaline content than regular engine oil, it cleans carbon sludge more efficiently. Therefore, when you first use LUBEKAT, the oil filter will contain more carbon sludge than usual.

OIL FILTER

Therefore, at your first use of LUBEKAT, after about 1,000 km, you should implement a) the Initial Filter Replace.

a) Initial Filter Replace: Change the oil filter

*(After this initial filter change, you should only need to change the oil filter **about every 20,000 km.**)*

ENGINE OIL

After you start using LUBEKAT engine oil, if the oil level decreases, just add the amount of LUBEKAT needed to fill the oil level to the top. You should **check the oil level** about every 10,000 km.

At minimum, you should change the oil about every 150,000 km; but we recommend changing the engine oil about every 80,000 km.

When you make this change in engine oil, it will **NOT** be necessary to implement the **a) Initial Filter Replace** step, because there should no built-up carbon sludge.